


EHH3320NVK



Your unique kitchen - tailored to suit you

Combine this modular hob with other modular hobs from Electrolux to build your own tailored mix of cooking methods - choose from gas, induction and radiant.

Product Benefits & Features



Wipe clean instantly

make your adjustments.

Because the surface around the pans stays cool as you cook, you can get rid of spills as you go along. Nothing gets burnt on, and there's nowhere for dirt to hide. So spend less time cleaning and more time cooking.

Direct access to all your controls - thanks to the on-

always access them straight away. Just reach over and

This hob's controls are designed so that you can

- Key-lock function
- · Built-in cutting radius: 5
- Pot detection
- · Hob with bevelled frame
- · Ceramic glass colour: Black
- · Easy installation thanks to snap-in system · Induction zones with power booster function
- Automatic fast heating up
- Stop and Go function for short interruptions
- Colour of designs on ceramic class: Stainless Steel
- · Child safety lock function
- Hob
- Illuminated controls
- Controls position: Front Middle
- Hob safety: Automatic Switch Off
- · Automatic safety switch off
- Hob type: Induction
- Appliance WxD in mm: 290 x 520
- Timer function
- · Main colour: Black



Boost the heat for instant results

When you need to cook really rapidly, the Booster function is perfect. Touch it for an instant burst of heat to boil water in under 90 seconds* - that's even faster than an electric kettle. It's great for last-minute vegetables and other quick cooking jobs too, like cooking pasta and rice.

Remembers where you left off

Whenever you get interrupted, you can put your cooking on hold with the Pause button. It makes sure nothing burns if you're called away from the kitchen and, conveniently, it remembers the different heats under all your pans. So when you're ready, one touch puts you back exactly where you left

A heat zone that only heats up when there is a pan on top

Thanks to its clever induction technology, this hob's heat zones only heat up when there is a pot on top. And as soon as the pan is removed, it deactivates itself.



EHH3320NVK

Product Specification

Induction Full
No
1.1
3700
0
220-240
IT
949 738 726
Not applicable
290x520
5.6
85166050
7332543453856

